DXF to G Code Troubleshooting

- If you open a file and the cursor changes to a hand, only allowing you to pan the screen, closing the app and reopening it should fix that problem.
- To get a DXF file created by Solidworks to work in the DXF to G Code app, ensure that "automatic cutter compensation" is turned off. The app will crash any time automatic cutter compensation is turned on.



• When trying to do cutter compensation, if you get an error in the command line reading:

"Cannot do cutter compensation, please check file / diamter of tool Not able to finish cutter compensation without error -Skipping it"

First, ensure that you're using tool 2, as this has the appropriate diameter of the cutting tool given that the wiki states "The kerf is about 800 microns wide."

1 1 3 10 12 2 Z Infeed depth [mm] 0.0 1.0 Feed rate XY [mm/min] Feed rate Z [mm/min] Block 0 includes 0 Geometries, reduced to 0 Contours, used layers: []	2		~
3 10 12 Z Infeed depth Z Final mill depth [mm] 0.0 Intervention Z Final mill depth [mm] Feed rate XY [mm/min] Feed rate Z [mm/min] Block 0 includes 0 Geometries, reduced to 0 Contours, used layers: []	2		
10 12 Z Infeed depth [mm] 0.0 Z Final mill depth [mm] 1.0 Feed rate XY [mm/min] 4.0 Feed rate Z [mm/min] 150.0	3		
Z Infeed depth [mm] 0.0 Z Final mill depth [mm] 1.0 Feed rate XY [mm/min] 4.0 Feed rate Z [mm/min] 150.0 Block 0 includes 0 Geometries, reduced to 0 Contours, used layers: []	10		
Z Final mill depth [mm] 1.0 Feed rate XY [mm/min] 4.0 Feed rate Z [mm/min] 150.0 Block 0 includes 0 Geometries, reduced to 0 Contours, used layers: []	Z Infeed depth	ifeed depth [mm]	0.0
Feed rate XY [mm/min] 4.0 Feed rate Z [mm/min] 150.0 Block 0 includes 0 Geometries, reduced to 0 Contours, used layers: []	Z Final mill depth	inal mill depth [mm]	1.0
Feed rate Z [mm/min] 150.0 Block 0 includes 0 Geometries, reduced to 0 Contours, used layers: []	Feed rate XY	ed rate XY [mm/min]	4.0
Block 0 includes 0 Geometries, reduced to 0 Contours, used layers:	Feed rate Z	ed rate Z [mm/min]	150.0
Block 0 includes 0 Geometries, reduced to 0 Contours, used layers:			
Block 1 includes 0 Geometries, reduced to 0 Contours, used layers: [] Block 2 includes 0 Geometries, reduced to 0 Contours, used layers: [] Loaded 18 entity geometries; reduced to 3 contours; used layers: [0]; number of insert Drawing units: millimeters Cannot do cutter compensation, please check file / diamter of tool Not able to finish cutter compensation without error - Skipping it	Block 0 includes 0 G Block 1 includes 0 G Block 2 includes 0 G Loaded 18 entity ge Drawing units: millin Cannot do cutter o Not able to finish o	c 0 includes 0 Geometries, reduced to 0 C < 1 includes 0 Geometries, reduced to 0 C < 2 includes 0 Geometries, reduced to 0 C led 18 entity geometries; reduced to 3 co ving units: millimeters not do cutter compensation, please check able to finish cutter compensation withou	ontours, used layers: [] ontours, used layers: [] ontours, used layers: [] ntours; used layers: [0]; number of inserts 0 file / diamter of tool t error - Skipping it

• If it still doesn't work, ensure that the tool is programmed into the tool library with the appropriate dimensions. Get there with options, configuration, tools table. Check that tool 2 has a diameter of 0.80 and your configuration values in the general settings are in mm.

Configuration			? ×
Software config			
General settings	Define the tools here:		
Machine config			_
Output settings	name diameter speed	start_radius	
Automatic tool config	1 1 0 70 0 00 0 0 50		-
Table table			-
loois table	2 2 2 0.80 0.00 0.00	-	÷
Custom actions			•
	3 3 - 1.20 - 0.00 - 0.00		-
	4 10 10.00 1000 2.00		-
	5 12 0.10 0.00 0.20		-
			-
			T
			_
L			
		Discourse	
		Discard Close	Apply
		Discard Close	Apply
Configuration	· · · · · · · · · · · · · · · · · · ·	Uiscaro Ciose	Apply ? ×
	· · · · · · · · · · · · · · · · · · ·	Uiscard Ciose	? ×
Configuration	· · · · ·	Uiscard Close	? ×
Configuration Software config General settings		Uiscard Close	Appiy ? ×
Configuration Software config General settings Machine config	3D mode (requires OpenGL - restart needed)	Uiscard Close	Appiy ? ×
Configuration Software config General settings Machine config Output settings	3D mode (requires OpenGL - restart needed) Display dicabled native (default)	Uiscard Close	? ×
Configuration Software config General settings Machine config Output settings		Uiscard Close	? ×
Configuration Software config General settings Machine config Output settings Automatic tool config	☐ 30 mode (requires OpenGL - restart needed) ✓ Display disabled paths (default) ☐ Live update export route (default)	Uiscard Liose	арну ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table	□ 30 mode (requires OpenGL - restart needed) ☑ Display disabled paths (default) □ Live update export route (default) Melling -	Uiscard Close	Appiy ? X
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	☐ 3D mode (requires OpenGL - restart needed) ☑ Display disabled paths (default) ☐ Live update export route (default) Milling	Uiscard Close	Appiy ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	☐ 3D mode (requires OpenGL - restart needed) ✓ Display disabled paths (default) ☐ Live update export route (default) Milling ☐ Split line segments (default)	Uiscard Close	Appiy ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	30 mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default)	Uiscard Close	? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	30 mode (requires OpenGL - restart needed) Ø Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Ø Automatic cutter compensation (default)	Liscard Liose	Арриу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	30 mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default)	Uiscard Close	Арриу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Vautomatic cutter compensation (default) Machine type (default):	miling	Арриу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Miling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed):	miling	Арриу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed):	miling	Apply ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	30 mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output	miling	Apply ? × · · ·
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output	miling mm	Apply ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling mm	Арруу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Miling Split line segments (default) V Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling	Арруу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Valuomatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling mm	Арруу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	30 mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling	Арруу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling mm	Арруу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling mm	Арриу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Miling Split line segments (default) Vautomatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling mm	Арриу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Mathematic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling mm	Apply ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling	*
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Miling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling	Apply ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	30 mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling	Apply ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling	Арруу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling mm	Арруу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	30 mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling	Арриу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling miling	Apply ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling	Apply ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling miling	Арриу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling	Арриу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	30 mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling miling	Арриу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling mn	Арруу ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	30 mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Automatic cutter compensation (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling miling	Apply ? ×
Configuration Software config General settings Machine config Output settings Automatic tool config Tools table Custom actions	3D mode (requires OpenGL - restart needed) Display disabled paths (default) Live update export route (default) Milling Split line segments (default) Machine type (default): Configuration values use the unit (restart needed): Output Export the G-Code to stdout (instead of a file)	miling mm	Appiy ? ×

• If you still aren't getting cutter compensation, the next thing to try is a combination of a few steps. You'll need to try going to the options, and turning "split line segments" on. Then right click on a long line segment section towards the middle and click "set nearest start point." You should see the two arrows move near the point that you right clicked at.

Entities Lavers			Configuration	Ctrl+Shift+C
			Postprocessor configuration	Ctrl+Shift+P
	Na		Tolerances	
	0		Scale All	
□ ▷ Hol □ ▷ Hol □ ▷ Sha	Hol		Rotate All	
	Hol		Mirror All	
	Sha		Move Workpiece Zero	
		~	Split Line Segments	
			Automatic Cutter Compensation	
			Machine Type	•
			Measurement units	+

BXF2GCODE - [C:/Users/MFLAB USER/Downloads/Dogbone_withplates.DXF] **A** (1)

. ..



If that doesn't work when you try cutter compensation again, you may get an error stating, incredulously, "No intersection found?!"



For this, right clicking and selecting "switch direction" seems to help.



Now, the cutting path switches direction and "G41 Left Compensation" cuts inside the piece in this particular case.

Since we want to outline the piece to cut it out, we need to switch to "G42 Right Compensation."

