FormCure UV Curing Station 2025/12/17 21:27

# FormCure UV Curing Station



**Location:** Innovation Workshop

**Description:** Formlabs UV curing chamber

Manufacturer: Formlabs

### **About**

Some FormLabs Resins used in the Form 2 3D printer can benefit from post process curing. Each resin has a specific hardening curve which can be found within the reference material which will indicate the ideal time and temperature to be set on the FormCure.

## **Detailed Specifications**

• Max cure temp: 80 degrees C

• Light: 39W total drawn by 13 405 nm LEDs

# **Safety Concerns**

- Allow at least half an hour for IPA to evaporate before placing part in Form Cure
- Allow time for the Form Cure to cool off before removing parts
- Do not operate form cure with lid open

# **Operating Procedures**

1. Any part to be cured needs to be washed in the FormWash with IPA BEFORE being placed in the

form cure. Supports can be removed before or after curing process.

- 2. Wait 30 minutes after washing to allow all remaining IPA to evaporate
- Check the reference material for selected resin to determine ideal time and temperature for curing
- 4. Use the dial on the front of the FormCure to set time and temperature
- 5. Place part within the FormCure→ press start.

#### **Reference Documentation**

https://support.formlabs.com/s/article/Using-Form-Cure?language=en US

https://support.formlabs.com/s/article/Form-Cure-Time-and-Temperature-Settings?language=en\_US

https://support.formlabs.com/s/article/Form-Cure-Time-and-Temperature-Settings?language=en\_US

# **Training Documentation**

Form 2 Training SOP

From:

https://microfluidics.cnsi.ucsb.edu/wiki/ - Innovation Workshop Wiki

Permanent link:

https://microfluidics.cnsi.ucsb.edu/wiki/doku.php?id=formcure\_uv&rev=1672965482

Last update: 2023/01/06 00:38

