


Form Wash Cleaner

Form Wash Cleaner	
	
Tool Type: "Formlabs alcohol cleaner"	
Location: "Innovations Workshop"	
Supervisor	Tool Lead
David Bothman	"WW Name"
(805) 893-4125	(###) ###-####
bothman@cnsi.ucsb.edu	"WW Email"
Description: "Formlabs post print alcohol cleaning station"	
Manufacturer: "Formlabs"	

About

The Form Wash is a post processor for the Form 2 resin 3D printers. Using an alcohol bath, build trays and/or parts can be loaded into the Form Wash where all uncured resin from the surface of the prints is removed.

Detailed Specifications

Insert Text Here!

Safety Concerns

Insert Text Here!

Operating Procedures

1. Remove build platform from Form 2 3D printer, making sure to keep Tupperware under print to prevent drips
2. Wake the Form Wash using the large dial located bottom right of the front face, select "OPEN"
3. Load the build platform or optionally remove prints from build platform and load into Form Wash basket.
4. Using the dial select the desired amount of time, click "START"
5. When the wash is complete, Remove parts and/or build tray, and select "SLEEP".

NOTE: When the Form Wash in complete, the lid will automatically open, allowing alcohol to evaporate. Before leaving, make sure Form Wash is shut. DO NOT LEAVE AFTER STARTING FORM WASH!!!

Reference Documentation

https://support.formlabs.com/s/article/Using-Form-Wash?language=en_US

https://support.formlabs.com/s/article/Form-Wash-Time-Settings?language=en_US

Training Documentation

[Form 2 Training SOP](#)

From:
<https://microfluidics.cnsi.ucsb.edu/wiki/> - Innovation Workshop Wiki

Permanent link:
https://microfluidics.cnsi.ucsb.edu/wiki/doku.php?id=formwash_cleaner&rev=1602175504

Last update: **2020/10/08 16:45**

