

# Form 2/3 Training SOP

Last edited: Wei (8/25/22)

## Training Checklist:

- Safety: personal protective equipment, avoid eye contact with laser, avoid contaminating areas with resin
- Job Setup
  - On the computer: PreForm software, file orientation, adjusting supports, record in FBS, selected material and version match the resin type loaded in the desired printer
  - Printer: confirm print, avoid any spills
- Using the Form Wash: transport part and build platform, wash and allow time for IPA to evaporate
- Using the Form Cure: release part from build platform, adjust curing settings depending on resin
- Post Processing: break support material, abrasives to remove marks left by touchprints
- Replacing an empty resin cartridge with a full one of the same type
  - Remove and replace cartridges
  - Avoid spills
  - Mark off new build tanks when new resin cartridge is put into rotation
- Switching a printer from one type of resin to another
  - Remove build platform, resin cartridge, and resin tank
  - Cover resin tank
  - Insert resin tank, lock wiper blade, insert resin cartridge, replace build platform
  - Mark off new build tanks when new resin cartridge is put into rotation
- Maintenance: clean resin tank interior, filter resin, cleaning tank window

## Overview:

- This training provides an introduction to using and operating the FormLabs SLA 3D printers including:
  - File Types
  - Software
    - PreForm 3D
  - Safety
    - PPE for working with resin
    - Understanding transportation of uncured resin
  - Printer Use
  - Post Processing
    - Form Wash
    - Form Cure
  - Printer Maintenance
    - Switching Resin
    - Cleaning Build Tanks
    - Troubleshooting
- The Form 2/3 is a 3D printer that uses SLA (stereolithography) to make a part. In SLA, a laser beam is directed into a tank of photoreactive resin, which hardens to form a layer of the part. The first layer adheres to the build platform, and each following layer adheres to the previous

one. The finished part will be suspended upside-down above the resin tank. It has a build volume of 145 × 145 × 175 mm (5.7 × 5.7 × 6.9 in).

- The Form Wash is an automated washer that bathes the printed part in IPA (isopropyl alcohol) to wash off residual resin.
- The Form Cure is a chamber that exposes a printed part to UV light to finish the curing process. This is referred to as 'post-curing.'
- Remember to enter job information into FBS!

## Safety



- Nitrile or neoprene gloves (not latex), safety glasses, and a lab coat must be worn when working with liquid resin printers. Safety glasses and a lab coat are required for working around IPA (isopropyl alcohol) when the Form Wash is open.
- Avoid eye contact with laser. Do not remove the front or back panels of the printer.
- Care must be taken to prevent contaminating other areas with liquid resin - use containers to transport build platforms or parts that still have liquid resin on them.
- Dispose of resin contaminated gloves and other objects in the yellow hazardous waste bin in 2442.

## Job Setup


### On The Computer:

- On the desktop computer near the Form 2/3 printers, open the PreForm software from the start menu.



- To start a new print, click File > New
- File > Open, select the .STL or .OBJ file you want to print.
- Set the scale, orientation, supports, and layout.
  - Formlabs recommends orienting flat surfaces at an incline of at least 20°.
  - Avoid printing tall, thin features when using flexible resin as it tends to flex during printing, resulting in print failure
  - While PreForm may indicate that a part is printable, it is not an indication the print will be successful. Care must be taken to ensure the part is supported properly and that the material choice is suitable.
- If there is an  next to printability, add manual supports, change support density and touchpoint size as needed until it becomes a .
- Save the print job in your group folder.
- Record the material used and print time in the online log along with the other job information requested. The print log should be on the desktop or [Print Log](#)

- To start the upload, press the orange 'Print' button.
- Make sure the selected material and version match the resin type loaded in the desired printer. Choose a layer thickness—thicker layers correspond to a faster print but reduce vertical resolution.



On the

### Printer:

- Press the button on the Form 2/3 to confirm the print
- After the print is completed, slide out the build platform with the part attached and place it into a plastic bin with absorbent pad to catch any resin spill.
- Close the orange cover

### Using the Form Wash:

- Transport the part and build platform in the container to Fume Hood #4 in Elings 2442.
- Wear a lab coat and safety goggles, as the Form Wash contains IPA.
- Press 'Open'
- Slide the build platform into place
- Adjust the wash time to 15 minutes (20 for flexible & durable)
- Press 'Start'
- After the washing is over, press 'Open' and remove the build platform. Place it in the container.
- Press 'Sleep' to close the Form Wash
- Allow 30 minutes to pass for the remaining IPA on the part to evaporate

### Using the Form Cure:

- Release the part from the build platform:

- Place build platform on the removal jig. Tools are in the Fume Hood #4 in Elings 2442.
- Slide a removal tool under the angled edge of the part's base to separate it from the build platform.
- Lift the cover of the Form Cure. Place the part in the center of the turntable.
- Select the curing time and temperature. Curing settings are dependent on which resin is used.
- Refer to the webpage "Form Cure Time and Temperature Settings" through the Formlabs website for resin specific information. A longer cure time (up to an hour) will slightly increase the tensile strength of the part.
- Press 'Start'
- Lift the cover and remove the part once the post-curing has completed.

### Post Processing:

- Use snips or tweezers to break support material off of the part. Be careful when finishing delicate parts to avoid breaking off small features.
- Use abrasives such as sandpaper and files to remove marks left by touchpoints until the surface is satisfactory.

### Replacing an empty resin cartridge with a full one of the same type:

More information on the resin system and changing a cartridge can be found on the webpage "Formlabs Resin Tank Information" through the Formlabs website.

Both the resin cartridges and build platforms are cross compatible with both the Form 2/3 as well as the newer Form 3 3D printers however the build tanks are not interchangeable. Types of resins are distributed between the Form 2/3 and Form 3 based on frequency used as well as which benefit from the low force SLA process employed by the Form 3 and should not be swapped without consultation with the staff.

1. Remove the empty resin cartridge:
  1. Close the vent cap at the top right of the resin cartridge to prevent resin from spilling out once removed
  2. Hold the cartridge handle and lift to remove from the Form 2/3. Store the cartridge upright with the valve cover installed to protect storage surfaces from resin.
2. Insert a new resin cartridge:
  1. Shake and rotate the new resin cartridge to ensure that the resin is mixed thoroughly.
  2. Align the cartridge with the opening at the back of the printer. Push down on the cartridge handle until the top of the cartridge is level with the printer.
  3. Press open the vent cap to ensure the resin tank can fill correctly

**New build tanks should be marked off when a new resin cartridge is put into rotation. This allows us to keep track of the wear on the build tanks and troubleshoot the printers more easily. Each new build tank is marked with a countdown of the number of liters remaining. Continue to numbers off the list as new resin tanks are put into use.**

### Switching a printer from one type of resin to another

More information on the resin system and changing a cartridge can be found on the webpage "Formlabs Resin Tank Information" through the Formlabs website. This includes videos and animations.

1. Remove the build platform - this prevents resin from dripping onto the glass

2. Remove resin cartridge:
  1. Close the vent cap at the top right of the resin cartridge to prevent resin from spilling out once removed.
  2. Hold the cartridge handle and lift to remove from the Form 2/3. Store the cartridge upright with the valve cover installed to protect storage surfaces from resin.
3. Remove the resin tank
  1. Hold the front tabs of the resin tank
  2. Gently pull the front tabs of the resin tank to release the tank feet from the tank carrier. The Resin Tank LT wiper ejects during removal.
4. Cover the resin tank and store on the left side of the fume hood
5. Insert the resin tank for the resin that you plan to use
  1. Lift the Form 2/3 orange cover. Use the tank grips to hold the Resin Tank LT, with the wiper resting inside the tank. If the tank contains resin, cover the tank with the plastic lid to align the wiper and minimize the risk of spills during insertion.
  2. Align and insert the four small feet of the resin tank into the corresponding slots in the tank carrier on the printer.
  3. Hold the front tabs and carefully push the tank until the tank feet lock into the slots on the tank carrier. Check the touchscreen display to confirm that the Form 2/3 detects the tank. The Form 2/3 will only detect the tank when the tank is fully inserted.
6. Lock the wiper blade
  1. Align and insert the wiper foot into the wiper mount.
  2. Push the wiper toward the tank.
  3. Ensure the wiper foot is securely locked into the wiper mount.
7. Insert resin cartridge:
  1. Shake and rotate the new resin cartridge to ensure that the resin is mixed thoroughly.
  2. Remove the protective valve cover from the underside of the cartridge. Use the cover to protect the bite valve during storage.
  3. Align the cartridge with the opening at the back of the printer. Push down on the cartridge handle until the top of the cartridge is level with the printer.
  4. Press open the vent cap to ensure the resin tank can fill correctly.
8. Replace build platform
9. Make sure that all of the resin tanks are correctly labeled.

**New build tanks should be marked off when a new resin cartridge is put into rotation. This allows us to keep track of the wear on the build tanks and troubleshoot the printers more easily. Each new build tank is marked with a countdown of the number of liters remaining. Continue to numbers off the list as new resin tanks are put into use.**

## Maintenance

- Cleaning resin tank interior
  - Use the scraper from the finish kit to inspect the resin and the elastic layer. Starting from the top corner, gently scrape from top to bottom across the elastic layer.
  - Check for the following issues that may lead to print failures or any excessive wear that requires replacing the tank:
    - cured resin on the elastic layer
    - debris or failed prints in the resin
    - settled pigment on the elastic layer
    - punctures, cuts, or gouges in the elastic layer
    - excessive "clouding" or wear in the elastic layer

- Filtering Resin
  - Use a filter to remove any debris or small bits of cured resin floating in the tank. Clean, debris-free resin helps avoid print failures, which may damage the tank.
- Cleaning the tank window
  - Never use IPA on the acrylic tank window (it will cause cracks).
  - If dust, fingerprints, and/or contamination are present, clean the clear acrylic tank window with NOVUS No. 1 and a clean microfiber cloth. The clear acrylic tank window is located on the underside of the resin tank. Apply 1-2 full sprays of NOVUS No. 1, and wipe using long, sweeping strokes top to bottom and across the tank window. Fold the microfiber cloth after each swipe to prevent dust and debris from scratching the acrylic.

From:

<https://microfluidics.cnsi.ucsb.edu/wiki/> - **Innovation Workshop Wiki**

Permanent link:

<https://microfluidics.cnsi.ucsb.edu/wiki/doku.php?id=form2sop&rev=1661449144>

Last update: **2022/08/25 17:39**

