

Location

The ozone cleaner is located inside the fume hood closest to the Objet printer in the Microfluidics Lab in Elings Hall 3430.

Operating Procedures

1. Make sure pump is connected to correct vacuum chamber. One chamber is for PDMS only.
2. Place sample in chamber
3. Set valve to VACUUM
4. Turn timer to desired time
5. Wait
6. After time has elapsed set valve to OPEN
7. Wait for chamber pressure to equalize
8. Remove sample

From:

<https://microfluidics.cnsi.ucsb.edu/wiki/> - Innovation Workshop Wiki

Permanent link:

https://microfluidics.cnsi.ucsb.edu/wiki/doku.php?id=vaccum_chamber_sop&rev=1752788543

Last update: **2025/07/17 21:42**

